

Installation Instructions: Low Profile - No Pest Vent

Read all instructions before beginning installation for best end results.

1. Assemble tube (if applicable) and attach to faceplate with seam oriented up. Be sure all pre-stamped snaps are secure.
2. Insert tube through the hole in the building and confirm the faceplate is level.
3. Fasten faceplate to building with screws using the premolded mounting pattern. Please use screws that are appropriate for the building material you are fastening the vent to.
4. Confirm both doors are flush and closing without issue

Optional: Seal the top and sides of the faceplate with silicone if needed. Do not seal the bottom as this will not allow the moisture out that collects over time.

IMPORTANT:

Faceplate must be installed level so the doors close completely when not in use. An uneven installation will create a poor seal for doors.

Do not overtighten screws or this will deform the faceplate and the doors will not be flush when closed.

If attaching the metal tube to the faceplate the seam **MUST** be at the top or it will not allow for proper door closer.

When installing the vent it is important to hang the mounting plate vertical or slightly inward at the top for a better door seal.

The small flat square piece is the inner trim ring. This piece is for trimming around the pipe on the inside on your home or building. We provide this due to the hole possibly being cut larger than the actual size of the vent pipe. If not needed you may recycle it.

Thank you purchasing our Low Profile No Pest Vent. We appreciate your business.

P-tec Products, Inc.

Questions

Call: (616) 772-0659

Email: info@p-tecproducts.com

If you need to remove the old hood

1. Remove the screws from the old faceplate or hood using the appropriate screwdriver. Check the type of screws and replace with new versions or the type of screw that is appropriate for the material you are securing the vent to.
2. The hood may still be attached to the wall of the home after removing the screws. Check for any sealant or caulking from the previous install.
3. Use a utility knife to cut through the sealant and remove the hood.

Detach from Dryer Duct

The hood may be attached to the dryer duct inside the wall with a clamp or metal duct tape.

1. Remove the clamp or tape and free the old hood from the interior ductwork.