

Installation Instructions

Soffit/Eave No Pest Vent

Read all instructions before beginning installation

The Soffit/Eave No Pest Vent is intended to be placed for a soffit or eave venting system.

1. Confirm the soffit/eave opening is a 4 inch diameter
2. Place the vent into the opening confirming it will be flush with the soffit or eave
3. Secure the soffit/eave vent with screws
4. Confirm the doors are opening and closing without issue. If you are having issues confirm the vent is level and the screws are not overtightened causing the vent to become deformed.

IMPORTANT:

Face plate must be installed level so the doors can close completely. If installed unevenly the doors will have a poor seal and will not close completely.

Thank you purchasing our Soffit/Eave No Pest Vent. We appreciate your business.

P-tec Products, Inc.

Questions

Call: (616) 772-0659

Email: info@p-tecproducts.com